

Novel Bio Clean Material for Air Purification and Disinfection Systems in Indoor Environments in COVID-19 Pandemic

By
Haiyong Li

Shenzhen Kangfeng Environment Science &
Technology Development Co., Ltd



COVID-19

Pandemic



COVID-19 Dashboard by the Center for Systems Science and Engineering (CSSE) at Johns Hopkins University (JHU)



Last Updated at (M/D/YYYY)
2/15/2022, 2:20 AM

Total Cases
412,665,299

Total Deaths
5,820,309

Total Vaccine Doses Administered
10,221,130,070

Cases | Deaths by
Country/Region/Sovereignty

US
28-Day: **11,809,572** | **65,561**
Totals: **77,808,188** | **920,621**

France
28-Day: **7,568,233** | **7,862**
Totals: **21,855,090** | **135,802**

India
28-Day: **5,285,281** | **22,560**
Totals: **42,665,534** | **509,011**




Brazil
28-Day: **4,477,776** | **17,346**
Totals: **27,492,904** | **638,673**

Germany

28-Day Cases
83,140,530

28-Day Deaths
272,705

28-Day Vaccine Doses Administered
742,266,667



Weekly 28-Day

COVID-19

Safer at Home



**Leave home only
for essential work
or necessities**



**Practice good hygiene:
cover coughs and sneezes,
don't touch your face, and
wash hands often**



**Work remotely
whenever possible**



**Physical distancing
of at least 6 feet**



**Use cloth face coverings
when in public**



**Disinfect frequently
used items and touched
surfaces often**

Novel Bio Clean Material—AOP-KF[®] solid alkali



A large amount of hydroxyl radicals, oxygen radicals, peroxy radicals and other active particles are generated during reaction process

Fast reaction speed, the reaction rate constant is $10^6 \sim 10^{10} \text{ L}/(\text{mol} \cdot \text{s})$, 7 magnitude higher than Ozone

AOP-KF[®] solid alkali only effective on bacteria and virus, it is non toxic towards animals, plants etc.

*SGS tests shows "AOP-KF solid alkali does not produce any harmful material"

Principle: AOP-KF[®] solid alkali induces in-situ regeneration of hydroxyl radicals ($\cdot\text{OH}$), which slows the physical adsorption of water (crystal water) on the surface of the carrier (mesoporous material) without heating or light. In addition to the ionized hydrolysis of OH , there is also non-ionized (radical) hydrolysis of chemically adsorbed water (OH). The latter is not significant under normal circumstances, but will greatly increase when the substrate reacts with it or is physically or chemically catalyzed. Accelerate, so that a large number of active particles such as OH are produced. $\cdot\text{OH}$ oxidation potential is high (2.80eV), and the chemical reaction rate constant is $10^6 \sim 10^{10} \text{ L}/(\text{mol} \cdot \text{s})$, which is 7 orders of magnitude higher than ozone, so the pollutant removal efficiency is high.

Inventor



Li Guopei
Chairman & Chief Scientist

- Deputy Director of Space Microbiology Data Center, Standing member of the Professional Committee of Space Microbiology and Infection of the Chinese Research Hospital Association; Interdisciplinary expert
- Former Deputy Director of Hangzhou Institute of Mechanical Science
- Presided over many major projects and won many awards
- Published multiple papers and held multiple patents



Li Guoqiao
Director & Co-founder

- Chief professor, doctoral supervisor, and former vice president of Guangzhou University of Chinese Medicine.
- Former director of Qinghao Research Center.
- Member of the Standing Committee of the Tropical Diseases and Parasitology Branch of the Chinese Medical Association.
- Master of clinical research on artemisinin drugs.



Chen Tangyi
Director & Co-founder

- Member of the Environmental Protection Leading Group of the Chinese Academy of Sciences.
- Former director of the Changchun Institute of Applied Chemistry, Chinese Academy of Sciences.
- The first director of Shenzhen Municipal Environmental Protection Bureau.
- Former director of the Planning and Budget Review Working Committee of the Standing Committee of the Shenzhen Municipal People's Congress, and former member of the Shenzhen Municipal Government's Science Advisory Committee.

AOP-KF® solid alkali-comparison with other technologies

| Disinfection technology | Mechanism of action | Pros and cons |
|-------------------------|--|---|
| AOP-KF® solid alkali | Using its strong oxidizing property, it destroys the micro-enzyme system, oxidizes and decomposes toxic substances such as formaldehyde. | Advantages: active sterilization, low dosage, fast action, non-toxic, harmless, no residue, no secondary pollution, 360-degree sterilization and disinfection without dead ends; a small amount of atomic oxygen released can also play a role in fresh air. |
| Plasma | The plasma matrix is used to form a high-voltage electrostatic field to decompose and destroy the negatively charged bacteria, so as to achieve the purpose of sterilization. | Disadvantages: It must be cleaned regularly, otherwise the efficiency will be significantly reduced; because of the high-voltage discharge, toxic ozone will be generated. |
| Ozone | The oxidizing property of ozone is used to achieve the effect of sterilization and disinfection, which is active sterilization. | Advantages: rapid purification effect, broad-spectrum sterilization. Disadvantages: Strict requirements for ozone concentration, difficult to control, and people and machines cannot be in the same room. |
| Ultraviolet rays | The oxidizing property of ozone is used to achieve the effect of sterilization and disinfection, which is active sterilization. | Advantages: convenience, no pollution to the environment, no residual toxic substances. Disadvantages: The effect is inversely proportional to the distance and area, only the surface of the object can be sterilized, which is harmful to the human body, and cannot be shared by humans and machines. |
| Photocatalyst | The oxidizing property of ozone is used to achieve the effect of sterilization and disinfection, which is active sterilization. | Disadvantages: Nano particles have a strong penetrating power to cells, and inhalation of the human body is likely to cause great harm. At present, some scientists have proposed to use nanotechnology with caution. |
| Negative ion | Using DC high voltage to generate high corona, release a large number of electrons at high speed, together with oxygen molecules in the air, form negative ions and diffuse outward. | Advantages: Negative ions are good for human health, can enhance disease resistance, promote metabolism, improve human sleep and so on. Disadvantages: Negative ions last for a short time in the air, cannot be sterilized, do not decompose harmful substances, and are ineffective against peculiar smells. |
| Activated carbon | It is a commonly used air purification material, which uses the porous structure of bamboo charcoal to adsorb traces of toxic gases in the air. | Advantages: easy to use Disadvantages: Passive physical adsorption is mainly used, and the adsorption capacity for long-distance pollutants is weak, and the adsorption capacity is limited, which is easy to cause secondary pollution. |



Conditions for Dynamic Sterilization

Continuous Filling, No Dead Corner

Metal Oxide Catalyst

Ozone

Low Concentration, Harmless

Hydro Peroxide

Ultraviolet

High Efficiency, No Drug Resistance

HEPA

Does Not Affect Environment

Potassium permanganate

Negative Ion

Easy to Use/Maintain, Long Life

Chlorine Dioxide Releasing Agent


Plasma

「Passive Disinfection」

When air flows through purification module, the carried pathogenic microorganisms are oxidized and eliminated .

Oxidative intermediates come into play :

Hydroxyl free radicals




[Active Disinfection]





A small amount of chlorine dioxide is released into the air. The concentration of chlorine dioxide can be kept constant below 0.03ppm, which is within the safe range of 0.1ppm specified by the World Health Organization WHO and the US EPA.




Does it work towards Covid?



| | Diameter (nm) | Radius(nm) | Volume (nm ³) |
|------------------|--|------------|---|
| Covid-19 |  100 | 50 |  523598.7667 |
| ClO ₂ | 0.36 | 0.18 | 0.024429024 |
| Ratio | 278 | 278 | 21,433,471 |

A soccer field is roughly 10,000 square meter. A soccer
takes roughly 0.05 square meter




Experiment video

Toast comparison video



Based on AOP-KF[®] solid alkali--medical products



YKJ2000F-A01

H1N1 influenza virus removal rate
15 minutes>99.99% (30m3)



YKJ450F-BG01

| Type | YKJ2000F-A01 |
|--|-------------------------------------|
| Field test (natural bacteria elimination rate) | 60min 99.92% |
| Sterilization rate (Staphylococcus aureus) | 15min >99.99% |
| Sterilization rate (Aspergillus niger) | 30min >99.96% |
| Virus removal rate | 15min >99.99% |
| | A/PR8/34 (Influenza A H1N1 virus) |
| PM0.1 | 8min >99.99% |
| PM2.5CADR | 1998.7 m ³ /h |
| Particle purification energy efficiency | 6.67 m ³ /(w·h) |
| Formaldehyde CADR | 431.1 m ³ /h |
| Toluene CADR | 123.8 m ³ /h |

| Wall-mounted air disinfection and purification machine YKJ450F-BG01 | | | |
|---|-------------------------|--|------------------------|
| Field test (Death rate of natural bacteria) | 60min 95.34% | Sterilization rate (Staphylococcus albicans) | 60min 99.99% |
| Particulate CADR | 431.3 m ³ /h | Formaldehyde CADR | 72.7 m ³ /h |
| Product Size | 1120×138×215 mm | Rated input power | 45w |
| product weight | 11kg | Noise | ≤46 dB |
| Power nature | AC220V 50Hz | | |

Medical Air Disinfection Purifier——Comparison



VS



VS



KangFeng : YKJ2000F-A01

A world known brand

A well-known domestic brand

| | | | |
|---------------|---|---|---|
| Tech | AOP-KF® Solid Alkali+Low Temp Plasma | Originated from International Space Station and Mir Space Station | High efficiency filtration and photoion |
| Sterilization | 15min>99.99%(30m ³ test chamber) | 60min>99.99%(20m ³ test chamber) | 60min>99.99% (30m ³ experiment cabin) Guangdong Microbial Analysis and Testing Center |
| Size | 1620*640*430mm | 1940*910*570mm (3.4X) | 800*520*1940mm |
| Power | 300W | 540W (3.6X) | 380W |
| Weight | 105kg | 140kg (2.3X) | No public data |

Medical Projects

Shanghai First People's Hospital

Shanghai Ruijin Hospital

The First Affiliated Hospital of
Kunming Medical University

Peking University Shenzhen
Hospital

Congdu International Life and
Health Management Center

Wuhan University People's
Hospital

The Fifth Affiliated Hospital of
Sun Yat-sen University

Union Hospital, Tongji Medical College,
Huazhong University of Science and Technology

Shanghai Bund Community Health Service
Center

Zhuhai People's
Hospital

Ganmei International Hospital, Kunming
First People's Hospital

Shanghai Tongren Hospital

Wuhan University People's
Hospital

The First Hospital of
Shanxi Medical University

Lhasa Armed Police General
Hospital, Tibet

The First Affiliated Hospital
of Nanchang University

The Eighth People's Hospital
of Guangzhou

Xiangyang First People's
Hospital

Guangzhou Hospital of Integrated
Traditional Chinese and Western Medicine

AOP-KF[®] solid alkali--household products

Efficiently remove aldehydes, and at the same time reduce the occurrence and cross-infection of respiratory tract infections in vulnerable populations such as the elderly and children.

Formaldehyde with a concentration of $1\text{mg}/\text{m}^3$ (10 times exceeding the standard)

5 minutes → drop to 0 (30m³)

H1N1 influenza virus removal rate

20 minutes > 99.99% (30m³)

Staphylococcus albicans removal rate

30 minutes > 99.99% (30m³)



kangfeng1hao



kangfengTake a deep breath



kangfengleju


kangfeng1hao pro

Comparison of AOP-KF® solid alkali technology at home and abroad-household products



kangfeng : KJ900F-H01

VS



A well-known brand in the world HealthPro GCX

VS



Pro XL, a world famous brand

| technology | High efficiency filtration + AOP-KF® solid alkali | H11 high efficiency + impregnated alumina and high-quality activated carbon | HEPASilent high efficiency + activated carbon |
|--|---|---|---|
| Particulate CADR | 871.9m³/h | 482.1m³/h | >800m³/h |
| Formaldehyde CADR | 2000m³/h | 421.6m³/h | 369m³/h |
| H1N1 influenza virus removal rate | 20min>99.99%(30m³) | — | — |
| Sterilization rate (Staphylococcus albicans) | 30min>99.99%(30m³) | 60min>99.9% | 60min>99.99% |
| size | 378*375*775mm | 410*380*1020mm | 504*240*1130mm |
| power | 85W | 135W | 120W |
| equipment weight | 15kg | 28kg | 32kg |
| price | 8998 ¥/set | 26,400 ¥/set | 25,800 ¥/set |

Shenzhen Audit Bureau

Shenzhen Longgang Financial Investment
Holdings Co., Ltd.

Shenzhen Longgang District Industrial
Investment Service Group
Limited company

Shanwei Municipal Ecological Environment
Bureau Shenshan Administration

China People's Health Insurance Co., Ltd.
Shenzhen branch

China Pacific Property Insurance Co., Ltd.
Shenzhen branch

Shenzhen Chunsongyuan Education
Management Co., Ltd.

School of Public Health, Sun Yat-sen
University

School of Life Sciences, Shenzhen University

The Experimental School of the High School
Affiliated to Peking University

Hitachi (China Research and Development Co.,
Ltd.)

Ziru Apartment

Household Projects

Guangzhou Zhongrun Industrial Co., Ltd.

Vanke Boyu Apartment

Shenzhen Bay Mansion

Blue Horizon Hotel Jinan

Jinbaolai Hotel Macau

Poly Hotel Guangzhou

Shenzhen Kylinhui Seafood Hotpot
Restaurant

Shenzhen Donghai New Life Catering
Culture Management
Limited company

Colorful Life Group Co., Ltd.

Shenzhen Silico Co., Ltd.

Da'ansheng Green Home Furnishing
(Guangdong) Co., Ltd.

Shenzhen Delsheng Technology Development
Co., Ltd.

Huawei Technologies Co., Ltd

AOP-KF® Solid alkali-mask test report



▲ Can be reused for 7 days


▲ Relieve rhinitis, bronchitis, asthma and other respiratory diseases

Table 6: Colony-Forming Units (CFU) present on interior and exterior of AOP-KF face mask over a period of 7 days.

| DAY | AOP-KF Inside Mask (EXHALED)- CFU/ 25CM ² | AOP-KF Outside Mask (INHALED)- CFU/ 25CM ² |
|-----|--|---|
| 1 | <1 | <1 |
| 2 | <1 | <1 |
| 3 | <1 | <1 |
| 4 | <1 | <1 |
| 5 | <1 | <1 |
| 6 | <1 | <1 |
| 7 | <1 | <1 |

▲ South Africa sterility test report

| | | | |
|--|---|---|---------------|
| 2. 过滤效率 (%) Filtration efficiency (GB 2626-2006) | 用氯化钠颗粒做检测; NaCl Non-oil aerosols KN95≥95.0 | (GB 2626-2006) 未预处理样品 Untreated sample: 1#: 98.08 2#: 98.25 3#: 97.97 | 符合 Conform |
|--|---|---|---------------|



| | | | |
|--------------------|----------------------|-------------------|-------------|
| Test Report | No. HK4C2001000553HC | Date Jan 31, 2020 | Page 2 of 3 |
|--------------------|----------------------|-------------------|-------------|

Test Requested, Test Method and Test Results

The analyses were performed with reference to:

Assessment of Antibacterial Finishes on Textile Material (AATCC 100-2012)

Test bacteria: *Staphylococcus aureus* (ATCC 6538)

| Tested Specimen | Bacterial count (colony forming unit, CFU per ml) over contact period | | Result: % of reduction of bacteria | Specified requirement | Comment |
|--------------------------|---|--------------------|------------------------------------|-----------------------|---------|
| | 0 hour | 24 hours | | | |
| As received | 1.80×10^6 | <100 | >99.94 | Minimum 99 % | Pass |
| Untreated control sample | 1.28×10^6 | 2.50×10^7 | - | - | - |

Test bacteria: *Klebsiella pneumoniae* (ATCC 4352)

| Tested Specimen | Bacterial count (colony forming unit, CFU per ml) over contact period | | Result: % of reduction of bacteria | Specified requirement | Comment |
|--------------------------|---|--------------------|------------------------------------|-----------------------|---------|
| | 0 hour | 24 hours | | | |
| As received | 1.20×10^6 | <100 | >99.92 | Minimum 99 % | Pass |
| Untreated control sample | 1.04×10^6 | 3.15×10^6 | - | - | - |

▲ Particulate matter filtration efficiency **KN95≥95%**

▲ The filtration efficiency of *Staphylococcus aureus* bacteria is **99.12%**

▲ *Klebsiella pneumoniae* removal **>99.92%**

| | | | |
|---|--|--|--|
| 广东省药品监督管理局医疗器械检验站 检验报告 报告编号: YD-2020-0001 产品名称: 医用外科口罩 规格型号: KN95 生产单位: 深圳市德安医疗器械有限公司 委托单位: 深圳市德安医疗器械有限公司 检验项目: 微生物检测 (细菌、真菌、病毒) 检验日期: 2020年12月20日 检验地点: 广东省医疗器械检验站 检验结果: 符合标准要求 检验结论: 合格 检验员: 李小明 审核员: 张小红 批准员: 王小明 | | | |
|---|--|--|--|

Cytotoxicity level 1
Skin irritation score 0
Sensitization: (No sensitization)

AOP-KF® Solid Alkaline Cloth—Test Report

|  <p>报告编号: ATCCR032011F</p> <h2>检测报告</h2> <p>样品名称: AOP-KF® 固体碱性 cloth</p> <p>委托单位: 北京康威 (上海) 科技发展有限公司</p> <p>检测项目: 菌落总数</p> <p>报告日期: 2020年12月16日</p> <p>北京康威分析测试中心有限公司 Beijing Kangwei Analytical Testing Center Co., Ltd.</p> | | <p>报告编号: ATCCR032011F</p> <h3>一、检测信息</h3> <table border="1"> <tr> <th>检测项目</th> <th>检测方法 (标准)</th> <th>检测标准</th> <th>结果</th> </tr> <tr> <td>菌落总数</td> <td>GB 4789.1-2016</td> <td>GB 4789.1-2016</td> <td>1.0E+01</td> </tr> <tr> <td>大肠菌群</td> <td>GB 4789.3-2016</td> <td>GB 4789.3-2016</td> <td>1.0E+01</td> </tr> <tr> <td>金黄色葡萄球菌</td> <td>GB 4789.10-2016</td> <td>GB 4789.10-2016</td> <td>1.0E+01</td> </tr> <tr> <td>霉菌和酵母菌</td> <td>GB 4789.15-2016</td> <td>GB 4789.15-2016</td> <td>1.0E+01</td> </tr> </table> <p>检测结果: 菌落总数: 1.0E+01</p> <p>检测单位: 北京康威分析测试中心有限公司</p> <p>检测日期: 2020年12月16日</p> <p>检测地点: 北京康威分析测试中心有限公司</p> <p>检测人员: 张红</p> <p>审核人员: 张红</p> <p>报告编号: ATCCR032011F</p> | | 检测项目 | 检测方法 (标准) | 检测标准 | 结果 | 菌落总数 | GB 4789.1-2016 | GB 4789.1-2016 | 1.0E+01 | 大肠菌群 | GB 4789.3-2016 | GB 4789.3-2016 | 1.0E+01 | 金黄色葡萄球菌 | GB 4789.10-2016 | GB 4789.10-2016 | 1.0E+01 | 霉菌和酵母菌 | GB 4789.15-2016 | GB 4789.15-2016 | 1.0E+01 | <p>报告编号: ATCCR032011F</p> <h3>二、检测数据</h3> <table border="1"> <tr> <th>检测项目</th> <th>检测结果 (CFU/g)</th> <th>检测结果 (CFU/g)</th> <th>检测结果 (CFU/g)</th> </tr> <tr> <td>菌落总数</td> <td>1.0E+01</td> <td>1.0E+01</td> <td>1.0E+01</td> </tr> <tr> <td>大肠菌群</td> <td>1.0E+01</td> <td>1.0E+01</td> <td>1.0E+01</td> </tr> <tr> <td>金黄色葡萄球菌</td> <td>1.0E+01</td> <td>1.0E+01</td> <td>1.0E+01</td> </tr> <tr> <td>霉菌和酵母菌</td> <td>1.0E+01</td> <td>1.0E+01</td> <td>1.0E+01</td> </tr> </table> <p>检测结果: 菌落总数: 1.0E+01</p> <p>检测单位: 北京康威分析测试中心有限公司</p> <p>检测日期: 2020年12月16日</p> <p>检测地点: 北京康威分析测试中心有限公司</p> <p>检测人员: 张红</p> <p>审核人员: 张红</p> <p>报告编号: ATCCR032011F</p> | | 检测项目 | 检测结果 (CFU/g) | 检测结果 (CFU/g) | 检测结果 (CFU/g) | 菌落总数 | 1.0E+01 | 1.0E+01 | 1.0E+01 | 大肠菌群 | 1.0E+01 | 1.0E+01 | 1.0E+01 | 金黄色葡萄球菌 | 1.0E+01 | 1.0E+01 | 1.0E+01 | 霉菌和酵母菌 | 1.0E+01 | 1.0E+01 | 1.0E+01 |
|--|-----------------|--|--------------|------|-----------|------|----|------|----------------|----------------|---------|------|----------------|----------------|---------|---------|-----------------|-----------------|---------|--------|-----------------|-----------------|---------|---|--|------|--------------|--------------|--------------|------|---------|---------|---------|------|---------|---------|---------|---------|---------|---------|---------|--------|---------|---------|---------|
| 检测项目 | 检测方法 (标准) | 检测标准 | 结果 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 菌落总数 | GB 4789.1-2016 | GB 4789.1-2016 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 大肠菌群 | GB 4789.3-2016 | GB 4789.3-2016 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 金黄色葡萄球菌 | GB 4789.10-2016 | GB 4789.10-2016 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 霉菌和酵母菌 | GB 4789.15-2016 | GB 4789.15-2016 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 检测项目 | 检测结果 (CFU/g) | 检测结果 (CFU/g) | 检测结果 (CFU/g) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 菌落总数 | 1.0E+01 | 1.0E+01 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 大肠菌群 | 1.0E+01 | 1.0E+01 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 金黄色葡萄球菌 | 1.0E+01 | 1.0E+01 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 霉菌和酵母菌 | 1.0E+01 | 1.0E+01 | 1.0E+01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

分析检测报告

报告编号: ATCCR032011F

检测项目: 菌落总数

检测结果: 1.0E+01

检测单位: 北京康威分析测试中心有限公司

检测日期: 2020年12月16日

检测地点: 北京康威分析测试中心有限公司

检测人员: 张红

审核人员: 张红

报告编号: ATCCR032011F

分析检测报告

报告编号: ATCCR032011F

检测项目: 菌落总数

检测结果: 1.0E+01

检测单位: 北京康威分析测试中心有限公司

检测日期: 2020年12月16日

检测地点: 北京康威分析测试中心有限公司

检测人员: 张红

审核人员: 张红

报告编号: ATCCR032011F

检测报告

报告编号: ATCCR032011F

检测项目: 菌落总数

检测结果: 1.0E+01

检测单位: 北京康威分析测试中心有限公司

检测日期: 2020年12月16日

检测地点: 北京康威分析测试中心有限公司

检测人员: 张红

审核人员: 张红

报告编号: ATCCR032011F

检测报告

报告编号: ATCCR032011F

检测项目: 菌落总数

检测结果: 1.0E+01

检测单位: 北京康威分析测试中心有限公司

检测日期: 2020年12月16日

检测地点: 北京康威分析测试中心有限公司

检测人员: 张红

审核人员: 张红

报告编号: ATCCR032011F



SARS-CoV-2 elimination rate **99.31%**

Testing standard: ISO 18184:2019

Respiratory syncytial virus inactivation rate **99.27%**

H1N1 inactivation rate **99.35%**

Application in the automotive industry (AOP-KF solid alkali technology)



In the new car, the original air filter is replaced by a filter of AOP-KF solid alkali.
The detected formaldehyde concentration has changed from 0.13-0.15 ppm to 0.

Based on AOP-KF ® solid alkali-portable disinfection machine travel application



Based on AOP-KF[®] solid alkali disinfection and purification equipment

AOP-KF[®]康风柜式空气消毒净化机



| 设备参数 | |
|-----------------|-------------------------------------|
| 电源 | 220V50Hz |
| 输入功率 | 200W |
| 噪声 | ≤50dB (A) |
| 处理风量 | 1300m ³ /h |
| 除菌率 (60 分钟) | 99.99%, 可快速去除甲型流感病毒、霉菌及细菌 |
| 颗粒物洁净空气量 (CADR) | >600 m ³ /h |
| 甲醛洁净空气量 (CADR) | >120 m ³ /h |
| 熔断器规格 | AC250, 2A |
| 外形尺寸 | 1780×560×290 |
| 产品重量 | 58kg |
| 产品主要成分 | 预过滤器、HEPA 过滤器、紫外光、负离子、AOP 固体碱反应器等组成 |

Floor cabinet machine




Large wind cabinet machine



单向流人字形过

Ceiling ceiling machine



Air conditioning reaction section

Application Cases of Fighting the Epidemic



Covid Test Vehicle



Live photos

One Belt One Road Environmental Technology Exchange and Transfer Center (Shenzhen)

Kangfeng from internal construction, energy efficiency management, efficient use of resources, adhering to the concept of "green, low-carbon", taking the highest standard of indoor environment in Northern Europe as our goal, and building the Belt and Road Environmental Technology Exchange and Transfer Center (Shenzhen) into a nationwide The first "Respiratory Health and Safety Demonstration Base". With the help of this national platform, we will showcase and promote our China's clean technology to countries all over the world.

Results

| Test Substance | Air Quality Standards | After Kangfeng Purification |
|----------------|----------------------------------|---------------------------------|
| Formaldehyde | $\leq 0.1\text{mg}/\text{m}^3$ | $\leq 0.03\text{mg}/\text{m}^3$ |
| PM2.5 | $\leq 75\text{ug}/\text{m}^3$ | $\leq 15\text{ug}/\text{m}^3$ |
| Bacteria | $\leq 2500\text{cfu}/\text{m}^3$ | $\leq 150\text{cfu}/\text{m}^3$ |

Solve the problem of cross-infection of respiratory infectious diseases in the public environment, and fundamentally eliminate the possibility of large-scale respiratory disease outbreaks, such as influenza and tuberculosis.

Specify exclusive epidemic prevention unit



Science and technology
Winter Olympics
achievements exhibition
is exclusive Epidemic
prevention support units



Canton Fair
exclusive
Epidemic
prevention
support units



2022 Beijing Winter Olympics venues (ice altar)



The 2022 Beijing Winter Olympics has a total construction area of 33,220 square meters, and the main building is 30.15 meters high. The stadium includes two standard ice rinks, two on-land training venues, as well as supporting functions such as scientific research, medical, rehabilitation rooms, athletes' dormitories and restaurants.



Target Air Quality



2022 Beijing Winter Olympics

Project Phase I

Dec. 2020

1 Floor of Standard ice rink air purification



floor cabinet machine

Project Phase II

Jun. 2021

Conference room on floor 2 & dining room for air purification

1 Floor of standard ice rink air quality visualization system

Air floor apartment room (33)

Air floor apartment room (33)

6 Apartment apartment (34)

Air cleaner



Visualization system



fresh air machine



Install solid base net



2022 Beijing Winter Olympics



1 Floor of Standard ice rink air purification

1 Floor of standard ice rink air quality visualization system

Conference room on floor 2 & dining room for air purification

Air floor apartment room (33)

Air floor apartment room (33)

6 Apartment apartment (34)



2022 Beijing Winter Olympics



The area of 3,000 square meters is 15 meters high
Maximum single space in the "ice altar" --the first layer of the standard ice rink

In 2020, COVID-19 ravaged the world, and crowds and cross-infection have become the biggest threat to public health security.

The project aims to create the highest level of super-large indoor space air quality level in the world, remove the pathogenic microorganisms in the air, and block the cross-infection route of respiratory infectious diseases. The application of this technology has cross-era significance.



fresh air ventilator



assembly room
212m²



office
434m²

2022 Beijing Winter Olympics



3 items of pollution data

other data



take down
Room return air outlet
Nylon filter net

fit on
Conwind solid
base net






Three tests for the total number of bacteria (the third-party test of Beijing spectral)

| | 设备进场前 2020.12.26 | 设备运行1日 2020.12.28 14:00~16:30 动态 上班时段现场70人 | 设备运行1日 2020.12.28 18:00~20:30 下班时段现场3人 | 设备运行3日 2020.12.30 18:00~20:30 下班时段现场3人 |
|----------------------------|---------------------|--|--|--|
| 细菌总数 (cfu/m ³) | 均值283 | 均值22 (去除率92.2%) | 均值17 (去除率94.0%) | 均值13 (去除率95.4%) |
| 甲醛 (mg/m ³) | 均值0.031 | 均值0.020 | 均值0.016 | 均值0.014 |
| PM10 (mg/m ³) | 均值0.045 | 均值0.021 | 均值0.015 | 均值0.003 |

The total number of bacteria, the equipment has reached the class I environment level of the hospital after operation

- The equipment operates for 1 day, under dynamic environment (about 70 people on site, dynamic in and out), and 13 detection points average 22cfu (colonies) / m³
- The equipment operated for 1 day, under static environment (3 number on site), and 13 detection points reached 17cfu (colonies) / m³
- The equipment operates for 3 days. In static environment (3 people on site), 13 detection points average 13cfu (colonies) / m³





Chlorine dioxide concentration test (the third-party test of Beijing Sinochem Institute)

| | | |
|---------------------|------------------|------------------|
| 二氧化氯浓度 (mg/m3) | 空气消毒净化机 5号 风口 | 空气消毒净化机 7号 风口 |
| | 0.011 | 0.014 |
| | 设备风口 平均值 : 0.013 | |

| | | |
|--------------------|-------|-------|
| 点位5 | 点位7 | 点位9 |
| 0.008 | 0.012 | 0.010 |
| 场地中间点位 平均值 : 0.010 | | |





Effectiveness & Security

The mean chlorine dioxide concentration actually detected in the venue was 0.010mg / m³, or 1/30 of the safety limit of 0.3mg/m³.

At such concentrations, as verified from the test results, the AOP-KF® solid base, while effectively in disinfection and sterilization.

Be able to ensure no toxic side effects.



| 采样日期 | 采样情况 | 菌落总数 cfu/m ³ | 颗粒物 mg/m ³ | 甲醛 mg/m ³ |
|-----------------------|--------------------|----------------------------|--------------------------|-------------------------|
| 2020.12.26 | 设备进场前 10人 | 283 | 0.046 | 0.031 |
| 2020.12.28 设备运行1日 | 14:00~16:30 70人 | 22 | 0.021 | 0.02 |
| | 18:00~20:30 3人 | 18 | 0.015 | 0.016 |
| 2020.12.30 设备运行3日 | 18:00~20:30 3人 | 14 | 0.003 | 0.014 |
| 2021.01.29 设备运行1个月 | 15:00~17:30 60人 | 28 | 0.007 | 0.015 |
| | | 23 (3.3米高) | / | / |
| | 18:00~20:30 3人 | 104 | 0.005 | 0.03 |
| 2021.03.30 设备运行3个月 | 15:00~17:00 70人 | 112 | 0.027 | 0.03 |
| | 18:00~20:30 6人 | 145 | 0.024 | 0.029 |
| 2021.06.10 设备运行6个月 | 10:00~12:00 70人 | 47 | 0.021 | 0.042 |

| 采样日期 | 净化机5号 | 净化机7号 | 点位⑤ | 点位⑦ | 点位⑨ | 平均值 |
|-----------------------|-------|-------|------------------|------------------|------------------|--------|
| 2020.12.30 设备运行3日 | 0.011 | 0.014 | 0.008 | 0.012 | 0.010 | 0.0110 |
| 2021.01.29 设备运行1个月 | 0.009 | 0.011 | 0.007 | 0.010 | 0.011 | 0.0096 |
| | / | / | 0.003 (3.3米高) | 0.003 (3.3米高) | 0.004 (3.3米高) | 0.0033 |
| 2021.03.30 设备运行3个月 | 0.007 | 0.010 | 0.009 | 0.006 | 0.011 | 0.0086 |
| 2021.06.10 设备运行6个月 | 0.010 | 0.008 | 0.012 | 0.009 | 0.007 | 0.0092 |

The Capital Gymnasium, the Athletes' Apartment



More than 60 national short-track speed skaters are ready to move in the First Sports Athletes Apartment.

The 2nd and 3rd floors of the apartment have just been renovated, and the interior taste is big.

For the health of athletes, the air purification equipments of Shenzhen Kangfeng environment is used to control the decoration pollution.

The air quality of the air purification equipment can meet the highest standard of the hospital class I environment and the indoor environment in northern Europe.



Chinese ice and snow athletes travel protection



China Ice and Snow partners

The Chinese figure skating team --
masks and gloves

The world's first Functional mask
that can kill the novel coronavirus

Travel escort



@喵大白话

Broad application scenarios



Home



Business



School




hospital



Confinement
Center



Nursing
home



Space station



Pet shop



Farm



Public places



Kangfeng Respiratory Safety Guard